

GTE SYLVANIA

INCORPORATED

FACTORY PREPARED TECHNICAL SERVICE DATA

STEREO HI-FI
SUPPLEMENT 2 TO
BULLETIN: P63-2

MODEL: MS3712W

SERVICE PUBLICATIONS DEPARTMENT
Entertainment Products Group 700 Ellicott Street - Batavia, N.Y.

SUPPLEMENT 2 TO BULLETIN: P63-2

SUPPLEMENT 2 TO BULLETIN: P63-2

This Bulletin introduces model MS3712W.

The P63-3 is identical to the P63-2, except for the following:

1. Addition of Tape and Speaker sockets.
2. Addition of Function and On-Auto/Off switches.
3. Switches and Headphone socket are mounted on a separate bracket attached to the cabinet.
4. Leads from points LA and RA, on printed circuit panel, are connected to Function switch.

For record changer information, refer to Supplement 1 to Bulletin R/C C129.

For chassis information not contained in this supplement, refer to Supplement 1 to Bulletin P63-2.



MODEL: MS3712W
CHASSIS: P63-3
R/C: C129R (11-34974-5)

CHASSIS REMOVAL

1. Using protective material as required, stand unit on side.
2. Remove six (6) screws from bottom cover and lift off.
3. Remove four (4) control knobs by pulling straight off.
4. Remove one (1) nut and one (1) washer from treble and loudness controls.
5. Locate and remove twist ties as necessary.

CABINET PARTS

DESCRIPTION	SERVICE PART NO.	DESCRIPTION	SERVICE PART NO.
Cabinet - Base	10-34476-101	Knob - Control	74-34231-2
Cabinet - Bottom Cover	85-34481-1	Nut - Headphone Socket	70-32649-1
Cabinet - Bottom Cover - Foot	86-91119-3	Record Changer - Cartridge	11-34972-1
Cabinet - Extrusion	74-34484-1	Record Changer - Stylus	11-10329-30
Cord - AC	73-33071-41	Speaker - 4" PM	12-22858-1
Cord - Speaker	73-14921-1	Speaker - Box	10-34491-101
Dust Cover	10-34474-2	Speaker - Brad	70-28495-1
Dust Cover - Nameplate	74-34511-1	Speaker - Grille	10-34491-102
Escutcheon	74-34478-1	Speaker - Socket & Holder	89-31022-1
Escutcheon - Spacer	85-34479-1	Spindle - 45 RPM	11-28211-2
Eyelet - Chassis Mtg.	70-14635-3		

IMPORTANT: Always use genuine Sylvania replacement parts and tubes.