

# GTE SYLVANIA

AIR SUSPENSION SPEAKER

MODEL: FS48A


## FACTORY PREPARED TECHNICAL SERVICE DATA

SERVICE PUBLICATIONS DEPARTMENT

Entertainment Products Group

700 Ellicott Street - Batavia, N.Y.

MODEL: FS48A




DECORATIVE HANDLE  
(74-13827-152)

### — SPEAKER REMOVAL —


Air Suspension Speaker systems require a complete seal around all openings. Exercise caution in removal and replacement of speakers to insure an air-tight seal.

1. Remove backcover.
2. Remove screws from woofer enclosure and lift out.
3. Remove screws from speaker and lift from housing. Disconnect leads from speaker. Be sure to observe correct phasing when installing speakers. Commercial Mortite can be used for an air-tight mounting by forming a bead around the rim.

### — SCHEMATIC DIAGRAM —



### — SPEAKER WIRING DIAGRAM —



MODEL: FS48A

IMPORTANT: Always use genuine Sylvania replacement parts and tubes.

MODEL: FS48A

REPLACEMENT PARTS LIST

SERVICE PART NO.	DESCRIPTION
85-38057-1	Baffle - Speaker
41-14304-1	Capacitor 1MF/25V
41-14304-3	Capacitor 5MF/25V
73-10302-33	Connector Kit - Plug
73-10302-29	Connector Kit - Receptacle
73-34828-4	Cord - Speaker
74-13827-152	Decorative Handle
85-32713-1	Enclosure - Speaker
85-32586-3	Gasket - Speaker
36-62454-19	Resistor - 5.6 ohm, 5W
12-26977-2	Speaker - 2 1/2' PM
12-26878-1	Speaker - 3' PM
12-32413-2	Speaker - 10' PM
89-31022-1	Speaker - Jack Holder

CROSSOVER NETWORK

